

Milk carafe

Proper use

The milk carafe is used to store milk or alternative milk products in the refrigerator. Only briefly remove the carafe from the refrigerator when preparing a speciality coffee with milk.

For your safety

- Do not keep topping up the carafe with milk. Milk that has been in the carafe for too long may be spoiled.
- Keep the container away from sources of heat.
- After preparing the beverage, return the carafe to the refrigerator immediately.

Getting started

- i** Rinse out the milk container **5**, the silicone adapter **3** and the metal tube **4** thoroughly before using them for the first time.
- ▶ Insert the metal tube **4** into the silicone adapter **3**.
- i** There are two silicone adapters (black and white) supplied as standard to help differentiate between the various milk alternatives.
- ▶ Insert the silicone adapter **3** and metal tube **4** into the special recess in the lid **6**.
- ▶ Turn the lid **6** on the container **5**.
- ▶ Open the pivoting cover, add the milk to the container **5** and close the pivoting cover again.
- ▶ Insert the milk pipe **1** with the transparent connector **2** into the silicone adapter **3**. Then connect the milk pipe **1** with your automatic coffee machine.
- i** The milk pipe can be cut to the required size.

Cleaning and maintenance

- i** The milk container, the lid with pivoting cover, the silicone adapter and the metal tube are dishwasher safe. The pivoting cover can be carefully lifted off the container.
- i** In the interests of hygiene, we recommend changing the milk pipe on a regular basis (approx. every 3 months). Replacement pipes are available from specialised dealers.

- ▶ Remove the milk pipe and rinse it thoroughly under running water.
- ▶ Separate the container into its individual parts and clean these parts in the dishwasher.

